

# Shaving Stand Set



This is a Woodcraft set.

How to make Shaving Stand with Razor Handle & Brush

There are other suppliers, such as PSI and Rockler, and they have a selection of components also.

A lot of the kits look the same. But, some do vary.

**Be sure to Practice Good Shop Safety**

**3 Components:** (part #'s are Woodcraft #'s)

- **Shaving Stand Kit in Chrome**  
#153292 \$12.99
- **Kit for Badger Hair Shaving Brush**  
#151091 \$10.25
- **Razor Kit in Chrome**  
#151092 \$13.50

## Kit contents

- Each package's contents
  - Stand
  - Razor Handle
  - Brush Handle
- Instructions
  - Parts list
  - Preparing blanks
  - Mounting bushings and turning the blanks
  - Assembly

## Tools & Accessories needed:

- Lathe
- 7mm pen mandrel
- Mandrel saver
- Vertical drilling jig
- Bushings for Deluxe Razor and Shaving Brush Stand Kit #153294 \$4.99
- 7mm drill bit wood or acrylic
- 7mm barrel trimmer
- 20mm Forstner bit
- 5/16 drill bit
- 3/8 16NC tap
- Mini bottle stopper mandrel (I use a Rockler Item #: 53459 \$11.99) Woodcraft probably has a similar one. It has a base diameter of  $\frac{3}{4}$ " or 18.94 mm
- Additional tools as needed for cutting blanks, marking center, and drilling.

## Blank stock: (of material of your choice)

- Blank for the stand kit at least 3-5/16" long and  $\frac{3}{4}$ " square.
- Blank for the razor handle at least 2-5/8" long and  $\frac{3}{4}$ " square.
- Blank for the brush handle at least 2" long and 1-1/2" square.

In this project I am using a piece of Goncalo Alves. It has a nice color and fairly straight woodgrain like Zebrawood does, but the Goncalo Alves has a richer color.

**Links:**

**Finding Center with the Squid**

<https://youtu.be/xX9FqOJHafs>

**Vertical Drill Jig**

[https://youtu.be/SUgjpA83O\\_E](https://youtu.be/SUgjpA83O_E)

**PSI Pen Assembly/Disassembly Press**

<https://youtu.be/XBBxkWrQTMA>

## **Gary Lundgren Crafts**

Johnstown PA


814-410-2900

[www.GLCrafts.com](http://www.GLCrafts.com)



## Badger Hair Shaving Brush Kit

Product #151091



Use Rockler mini bottle stopper mandrel I have. Works perfect.

Drill 20mm forstner recessed hole for brush to glue into, then drill 5/16 hole and tap to 3/8 as with bottle stopper.

↳ use std bit to center hole best. Brad bit tends to wander.

### General Instructions

Whether you're a novice turner or a pro, you'll find these projects are all quick and easy to make. Using cut-offs and shorts, the type everyone saves but doesn't know what to do with, you'll find yourself making handsome, custom woodturning projects which are great for gifts or for sale. The following is general in nature, please refer to the instruction sheet on the opposite side for specific dimensions and sizes for your project.

#### 1. Cutting Blanks

Cut wooden blanks to the size specified in the enclosed instructions. For your safety, be sure that the blanks are solid and have no holes, checks or other defects.

#### 2. Drilling Blanks

Center and bore a hole through your stock as specified in the Project Instructions on the opposite side. The center of the blank can be located at the intersection of diagonal lines, drawn from opposite corners. All holes




Fig. 1

are easily drilled using a clamp and a drill press (FIG. 1). Before you start to drill be sure that your blank is at 90° to the drill press table. You may also chuck and drill the stock on your lathe.

#### 3. Gluing Blanks to Tubes

Rough the brass tube's surface with a fine grit sandpaper and use a quick drying CA type glue to secure the brass tubes into the blanks. Rotate the tube as you insert it to ensure maximum surface coverage of glue. If you find that CA glue is not providing adequate bonding, an alternative is any two part epoxy type glue.

#### 4. Sanding Blanks to Length

Using a belt or disc sander, square the ends of the brass tube/wood blank. The blank should be flush with the brass tube on both ends. Care should be taken to not sand




Fig. 2

into the tubes (FIG. 2). If any excess glue remains inside the tubes it should be gently scraped out.

#### 5. Mandrel Preparation

Woodcraft's new Pen and Pencil Maker's Mandrel system allows you to turn a variety of small projects without requiring the purchase of a unique, special mandrel each time. The only item you will need to purchase to turn new projects is the specially designed bushing set for the project of your choice. The mandrel is provided with either a #1 Morse Taper (141468) or a #2 Morse Taper (141469). If you prefer to use the mandrel in a three jaw chuck, simply loosen the Morse Taper set screw and slide the Morse Taper off of the shaft. Now the mandrel shaft may be mounted directly in your three jaw chuck. With the bushing sets specified on the project instruction sheet, mount your wood blanks and bushings as depicted for each project. With the mandrel mounted in your lathe, slide a bushing onto the mandrel, followed by a wood blank and a second bushing or spacer as required, followed by the second wood blank if required. With the wood blanks installed on the mandrel, secure the wood blank/bushing assembly using the washer and retaining nut provided. Bring up a live center in the tailstock to support the threaded end of the mandrel. Do not over tighten the tailstock or the mandrel will flex and bend causing oval shaped turnings.

#### 6. Turning Blanks

Place your tool rest parallel and as close as possible to the blank. Rotate the blank by hand to ensure it will not touch the tool rest when the lathe is turned on. Using a turning speed of approximately 1,000 RPM begin turning the blank to a diameter slightly larger than the bushings. You can work the stock down to just short of the desired design or diameter by carefully scraping or sanding.

#### 7. Finishing the Blanks

Blanks can be finished like any other wood project. Using a fine grit sandpaper, sand the blank until it is flush with the bushing for parallel sided projects or until the desired profile is obtained for custom projects. Use a wood filler, if desired, to fill any grain openings in the blank. Final sanding with a wet/dry paper will create a blank which is glass smooth. *Tip: We have found that use of Micro Mesh sanding paper (11L61) after wet/dry sanding creates a perfect, glass smooth finish.*

#### 8. Assembly

All parts should fit together as depicted in the parts diagram for each project. In some cases a pen press or machinists vise will be needed to completely press the parts together. Protect all plated parts from scratching by covering them with a cloth or thin pad before placing them in a vise. Proceed carefully, many of the kit components are delicate and uneven or excessive pressure will cause permanent damage.



## Badger Hair Shaving Brush Kit

Product #151091

### 1. Cutting Blanks

Cut blanks to measure approximately 1 1/2" x 1 1/2" x 2" long.

### 2. Drilling Blanks

This will require the two holes to be drilled in the center of the blank. The first hole will use a 20mm forstner bit and will need to be 3/8" deep. The second bore will be a 6mm bit and will need to be 1" deep or slightly longer than the threads of the mandrel.

### 3. Mandrel Preparation

Mount the mandrel on your lathe using a four jaw chuck using pin jaws, or a drill chuck. Next screw the blank onto the mandrel until the wood shoulders against the round stop collar. Supporting the other end of the blank with the tailstock, turn to your desired shape.

### 4. Turning the Blanks


Turn the blank to your desired shape or design.

### 5. Finishing the Barrels

Use any finish of your choice. (CA, Friction Polish, Wax)

### 6. Assembly

Unscrew the finished handle from the mandrel and place on a clean flat surface. We recommend using a five minute epoxy or thick CA glue for the next step. Apply adhesive to the interior of the large hole that was drilled in step 2, insert the white end of the badger hair brush down into the adhesive, wiping off any excess adhesive that may leak out immediately. Allow brush to cure at least 24 hours before using.



Use Rockler mini bottle stopper mandrel I have. Works perfect.

Drill 20mm forstner recessed hole for brush to glue into, then drill 5/16 hole and tap to 3/8 as with bottle stopper.

↳ use std bit to center hole best

↖ ~ Brad point bit tends to wander off center easily.

